


Columbia

PEAK PATROL



Epson VX63 - 3 Hand Day-Date Quartz Movement



HOW TO SET THE TIME

- 1) Pull out the crown to the P2 click position.
- 2) Turn the crown to set hour and minute hands.
(Check that AM / PM is set correctly.)
- 3) Push the crown back into the normal position.

HOW TO SET THE DATE

- 1) Pull out the crown to the P1 click position.
- 2) Turn the crown counter clockwise for date setting.
- 3) Turn the crown clockwise for day setting.
*Do not set the date between 9:00 P.M. and 1:00 A.M.
as this will cause a malfunction.
- 4) Push the crown back into the normal position.

PEAK PATROL



Epson VR32A - Chronograph-Date Quartz Movement

HOW TO SET THE TIME


- 1) Pull out the crown to the second click position.
- 2) Turn the crown to set hour and minute hands.
(Check that AM / PM is set correctly.)
- 3) Push the crown back into the normal position.

HOW TO SET THE DATE


- 1) Pull out the crown to the first click position.
- 2) Turn the crown to left for date setting.
- 3) Turn the crown to right for day setting.
*Do not set the date between 9:00 P.M. and 1:00 A.M. as this will cause a malfunction.
- 4) Push the crown back into the normal position.

HOW TO USE THE CHRONOGRAPH


- 1) Standard Measurement




- 2) Accumulated Elapsed Time Measurement



- 3) Split Time Measurement



- 4) Measurement of Two Competitors





PEAK PATROL




BJK014 Digital Movement

FEATURES

- 12 Digits LCD Display
- Display Hour, Minute, Second, Month, Day and Week
- Daily Alarm and Chime hourly
- Snooze
- 12 / 24H format selectable
- 1/100 second Chronograph with split functions
- EL backlight

OPERATIONAL MODES

Use Pusher B to advance through modes.





CHRONOGRAPH

- 1) Press Pusher D to start chronograph.
- 2) Press Pusher D to stop chronograph.
- 3) Press Pusher C to reset to 0.

CHRONOGRAPH - SPLIT LAPS

- 1) Press Pusher D to start chronograph.
- 2) Press Pusher C to split lap. Press Pusher C again to see running chronograph. Repeat for each lap.
- 3) Press Pusher D to stop chronograph.
- 4) Press Pusher C to reset to 0.

ALARM AND HOURLY CHIME

- 1) Press Pusher D to turn on/off Hourly Chime  and Alarm 

DAILY ALARM

- 1) Press Pusher C and Hour will flash. Press Pusher D to advance to desired Hour.
- 2) Press Pusher C to advance to Minute. Press Pusher D to advance to desired Minute.
- 3) Press Pusher C to confirm.

TIME SETTING

- 1) When entering Time Setting, the seconds will be flashing. Press Pusher D to reset to 0.
- 2) Press Pusher C to advance to Hour. Press Pusher D to increase the hour.
- 2) Press Pusher C to advance to Minute. Press Pusher D to increase the minute.
- 2) Press Pusher C to advance to Month. Press Pusher D to increase the month.
- 2) Press Pusher C to advance to Date. Press Pusher D to increase the date.
- 2) Press Pusher C to advance to Day. Press Pusher D to increase the day.