



## TRAILHEAD



### T030 Digital Movement

#### FEATURES

- 12 Digits LCD Display
- Display Hour, Minute, Second, Month, Day, Year (2000-2069) and Week .
- Dual Time
- 5 Alarms
- Hourly Chime
- 3 Count-Down Functions
- Daylight Savings Time
- Chronograph Function
- Split Operation Stopwatch
- 12 / 24H Format
- Auto Calendar
- 1/100 second Chronograph
- Key Tone
- EL Backlight

#### OPERATIONAL MODES



#### TIME SETTING

- 1) Press and hold Pusher D for 3 seconds to enter setting mode.
- 2) Press Pusher D to advance through each mode (second, minute, hour, year, month, day).
- 3) Press Pusher B to increase and C to decrease.
- 4) Press and hold Pusher D for 3 seconds to exit setting mode.

Note: While hour is flashing, press B or C until an "H" is displayed. This will enter 24H mode.

#### DAYLIGHT SAVINGS TIME

- 1) Press and hold Pusher D for 3 seconds to enter setting mode.
- 2) With minute flashing, press and hold pusher D for 3 seconds to enter daylight savings on/off mode.
- 3) Press Pusher C to set daylight savings to on/off.
- 4) Press and hold Pusher D for 3 seconds to exit setting mode.

#### DUAL TIME SETTING

- 1) Press Pusher C to enter Dual Time Mode.
- 2) Press and hold Pusher D for 3 seconds to enter setting mode.
- 3) With hour flashing, Press Pusher B to increase and C to decrease the hour.
- 4) Press and hold Pusher D for 3 seconds to exit setting mode.

#### ALARM AND HOURLY CHIME

- 1) In Alarm Mode, Press and hold Pusher D for 3 seconds to enter setting mode.
- 2) Press Pusher C to set alarm (🔊) to on/off and chime (🔔) to on/off.

#### ALARM SETTING

- 1) In Alarm Mode, Press Pusher C to select Alarm 1-5.
- 2) Press and hold Pusher D for 3 seconds to enter setting mode.
- 3) Press Pusher D to advance to each mode (hour, minute).
- 4) Press Pusher B to increase and C to decrease.
- 5) Press and hold Pusher D for 3 seconds to exit setting mode.

#### COUNT-DOWN TIMER SETTING

- 1) In Timer Mode, press Pusher C to select Timer 1-3. Each timer has a maximum count-down range (T1-90 minutes, T2-24 hours, T3-1,825 days)
- 2) Press and hold Pusher D for 3 seconds to enter setting mode.
- 3) Press Pusher D to advance to each mode (hour, minute).
- 4) Press Pusher B to increase and C to decrease.
- 5) Press and hold Pusher D for 3 seconds to exit setting mode.

Note: In T1, the count-down setting mode is in minutes. In T2, the count-down setting mode is the result of the setting time minus the current time. In T3, the count-down setting mode is the result of the setting date minus the current date.

#### CHRONOGRAPH SETTING

- 1) In Chronograph Mode, Press Pusher C to choose between SPLIT mode or LAP mode.
- 2) In LAP mode, Press Pusher D to start chronograph. Press D again to stop, and again to continue.
- 3) Press Pusher C to split lap. Press Pusher C again to record another lap. Repeat for each lap.
- 4) Press Pusher D to stop chronograph.
- 5) Press Pusher C to reset to 0.

- 1) In SPLIT mode, Press Pusher D to start chronograph.
- 2) Press Pusher C to complete first person's lap.
- 3) Press Pusher C again to complete second person's lap. Repeat until complete.
- 4) Press Pusher D to stop chronograph.
- 5) Press Pusher C to reset to 0.